



804-928-1839

www.tbamachine.com

[Email: todd@tbasuppressors.com](mailto:todd@tbasuppressors.com)

Jack peg Instructions for Hellcat Challenger, Charger, Demon, Redeye

Tools Required

13mm wrench or socket

8 mm allen wrench or 8mm socket drive

Long Jack pegs are for the Rear

Short Jack pegs are for the front

1. Support the vehicle on an automotive lift or with jack stands on concrete.
2. Remove the rear jack pegs with a 13mm socket. This hardware is used again for the long jack pegs. We have not provided hardware for the long jack pegs.
3. Install the new jack pegs and use the same hardware you removed from the OE (Original) pegs and apply Loctite to the bolts and torque to 30#.
4. Apply Loctite to the provided hardware and Install the short front jack pegs with an 8mm allen wrench, torque to 30# into the threaded inserts in the chassis. Some of the Hellcat Chargers do not have these in the frame rails. In that case remove the forward most support bolt in the front frame bracket beside the rocker panel and replace with the provided hardware.