



1. Remove your dipstick, clean the oil off and cut the top loop off leaving a minimum of .130" which is flush with the top, flat portion of the original pull stick. See the 1<sup>st</sup> picture on the top left. Deburr the round outside exterior portion that will be inside of the new cap.

2. Support the new cap in a rubber or padded vise and insert the dipstick inside of it while starting the snap ring with your finger. ( see the top right picture). Work the snap ring around and push it in with a small flatbladed screwdriver and the ring will snap into place and hold the cap in place.

