



11263 Air Park Rd. Ashland VA 23005 804-928-1839 [www.tbamachine.com](http://www.tbamachine.com)

## Tow Hook Installation Instructions

### Tools required

- 18mm socket
- Torque wrench
- 9/16 wrench or socket

### Rear Hooks

**Important: Only install 1 side at a time!**

1. Support the cross member at the lower control arm inner bolt and remove the 18mm bolt from the body mount.
2. Place the 1/8" thick washer on the body washer (as pictured below) and place the rear tow hook over the bolt and install it in whichever direction you prefer and torque it to 90 ft. lbs



### Front Hooks

1. Install the tab inside of the cross member as pictured below.
2. Apply Loctite and start the hardware with the washers until both are started by hand, tighten them by hand rotating from one to the other in even increments, then torque them to 26 ft lbs.

